

Topac

The Instrumentation Company

www.topac.com

Press Release

New Product information

8/2/99

Image and text available online at <http://www.topac.com/pressinfo.html>

New Digital Manometers (pressure gauges) feature 7 scales and data logging options with Windows software.

Topac introduces the Digitron 2000 range of digital manometers.

The Digitron2000 manometers are hand held pressure gauges covering the pressure range 2 inches of water to 7 atmospheres with 6 different models. The gauges feature high accuracy (0.2% of reading) and an extensive range of feature options including, sample and hold, maximum and minimum readings, smoothing to remove short term fluctuations, data logging, averaging and leak detection functions. The instruments are available in several different configurations of range and features for absolute and differential pressure. The basic manometers read in inches of water and other models can convert between eight different pressure scales – inches & mm H₂O, inches and mm hg, Bar & mbar, Pa and kPa . Users can even program in their own custom scale by keying in a scale factor. The data logging versions can store up to 250 readings and the information can be downloaded to a PC using a Windows program. A special feature of the download is the infra red link between the hand held unit and the interface box. All the 2000 series meet IP65 environmental standards and IP67 units are also available. Applications include laboratory monitoring work, quality control, and inspection and testing. The instruments can be purchased on line at www.instrumentsonline.com. And more information is available at <http://www.topac.com/pressure.html>



For more information call Antoni Drybanski 781 740 8778 (e-mail toni@drybanski.com) or see the web page for this product at <http://www.topac.com/pressure.html>

Topac Inc.

99 Derby Street, Suite 303, Hingham MA 02043 USA. Tel: 781 740 8778 Fax: 781 740 8779

E-mail: topac@drybanski.com Internet: <http://www.topac.com>